


INSTRUCTION MANUAL

Model 2850



ENVIRONMENTAL TEST CHAMBER

ENVIRONMENTAL CONTROL EQUIPMENT FOR RESEARCH AND INDUSTRY
5725 KEARNY VILLA ROAD • SAN DIEGO, CALIFORNIA 92123

SPECIFICATIONS

TEST AREA DIMENSION (H x W x D)	7" x 16" x 7" (17.78 x 40.64 x 17.78 Cm)
AIR CIRCULATION	140 CFM centrifugal blower with baffling provides equal distribution throughout the chamber in a horizontal air flow pattern.
INNER LINER	Type 302 Stainless Steel
OUTER CASE	Aluminum
INSULATION	Fiberglas
WEIGHT	52 lbs (23.6 Kg)
POWER REQUIREMENT	120 VAC, 50 or 60 Hz, Single Phase, 20 Amp or 240 VAC, 50 or 60 Hz, Single Phase, 15 Amp.
CONTROLS	POWER On-Off Switch and Light COOL On-Off Switch and Light HEAT On-Off Switch and Light TEMPERATURE SET Control MANUAL/PROGRAM Control Switch (MODE)
HEATING ELEMENTS	Two 20 ohm Elements to give a total of 1875 Watts, Nichrome Wire.
COOLING	Liquid Carbon Dioxide (LCO_2) or Liquid Nitrogen (LN_2)
PROGRAMMING	Programmable
COOL DOWN TIME	Ambient to -53°C in $3\frac{1}{2}$ minutes.
HEAT UP TIME	Ambient to $+217^{\circ}\text{C}$ in 9-3/4 minutes.

TEMPERATURE RANGE	-73°C to +315°C
RESETTABILITY	0.25°C
TEMPERATURE DEVIATION	0.1°C
LINE VOLTAGE STABILIZATION	0.25°C for 105 to 125 VAC, Line Voltage Change 0.25°C for 220 to 240 VAC, Line Voltage Change
AMBIENT TEMPERATURE COMPENSATION	$\pm 0.010^{\circ}\text{C}/^{\circ}\text{C}$
HEAT LOAD COMPENSATION	$\pm 0.040^{\circ}\text{C Watt}$
THERMAL IMPEDANCE OF CHAMBER	Approximately 1°C/Watt
NULL DETECTOR CONTACT CLOSURE	Temperature will be within $\pm 2^{\circ}\text{C}$ of final temperature at 3 minutes after closure occurs.
NULL DETECTOR CONTACT RATING	1 amp, 240V, with contact protection provided by user to protect against inductive loads.

NOTE: IT IS RECOMMENDED THAT THIS MANUAL
BE READ THOROUGHLY BEFORE CONNECTING
EQUIPMENT TO ELECTRICAL POWER SOURCE.

INTRODUCTION

The Model 2850 Environmental Test Chamber offers an internal working volume 7" high, 16" wide and 7" deep. Air flow is horizontal at 140 CFM with baffling to provide equal air distribution.

Temperature control of $\pm 0.1^{\circ}\text{C}$ provides the precision necessary for bread-board circuit testing.



Digitized by the Internet Archive
in 2026

https://archive.org/details/manualsplus_13338

CONTENTS

	<u>Page</u>
SPECIFICATIONS	i
INTRODUCTION	iii
ILLUSTRATIONS	v
1 CHAMBER AND CONTROLLER DESCRIPTION	1
1.1 Chamber	1
1.2 Solid State Controller	1
1.3 Null Detector Circuit	2
2 INITIAL SETUP	2
2.1 Electrical Connection	2
2.2 Liquid Coolant	2
2.3 Liquid Nitrogen	3
3 STARTING UP PROCEDURE	4
3.1 Precautions	4
3.2 Controls	5
3.3 FAILSAFE Adjustment	5
3.4 Setting the Dial Temperature Indicator	6
4 PROGRAMMING	7
5 WARRANTY	8

ILLUSTRATIONS

<u>Figure</u>		<u>Page</u>
1	Temperature Set Dial	6
-	Trouble Shooting: Electrical	9
2	Operating Instructions	10
3	Chamber Air Flow Pattern	11
4	CO ₂ - LN ₂ Valve Removal	12
5	Temperature Control System	13

1 CHAMBER & CONTROLLER DESCRIPTION

1.1 Chamber

1.1.1 The Model 2850 is a precision environmental temperature test chamber having a stainless steel interior, aluminum outer case and fiberglass insulation. The air circulation is closed and provided by a 140 CFM blower. The chamber is heated by applying full wave power to bobbin wound nichrome heating elements via the heat switch.

1.1.2 The chamber is cooled by injecting liquid CO₂ (liquid nitrogen in the LN₂ models) into the air stream through an expansion nozzle. The coolant flow is metered by a solenoid valve, controlled by a solid state switch.

The temperature control system is shown in block diagram form in Figure 5.

1.2. Solid State Controller

1.2.1 The controller compares the resistance of the temperature probe to the resistance of the TEMPERATURE SET potentiometer. (The resistance of a remote programming resistor is compared to the probe resistance if the MODE switch is in the program position).

1.2.2 The resistance of the probe will always be either less than, equal to or greater than the resistance of the TEMPERATURE SET potentiometer (program resistance). These three situations directly correspond to the chamber temperature being lower than, equal to, or higher than desired. The controller applies heat, coolant, or withholds both to obtain and maintain the selected temperature in the chamber.

1.2.3 Mode - The controller is a three mode unit, i.e.,

- a) Heat only
- b) No heat or coolant
- c) Coolant only

This mode of control insures that LCO₂ or LN₂ is not wasted in a continuous cycling of the heaters and coolant valve such as would be the case for a simple two state output controller.

1.2.4 Further information on the controller may be found in the complete Type III Controller Manual included as part of this information package.

1.3 Null Detector Circuit

1.3.1 A contact closure is provided at the rear which functions when the chamber reaches the indicated set point of the controller. This contact closure may be used to signal external equipment that the chamber has reached selected temperature.

1.3.2 The Delta Design Model 9308 HI-LO Programmer, Model 9311 TEN STEP Programmer, and the Model 9313 HI-LO-AMBIENT Programmer utilize the null contacts to start their timers when they are used with the chamber. This contact closure feature is most useful in automatic test programming applications.

2 INITIAL SETUP

2.1 Electrical Connection - Power connection should be an AC power source rated at 125V - 20 amps - 50/60 Hz or 240V - 15 amps - 50/60 Hz (240V option). THE CHAMBER MUST BE CONNECTED TO EARTH GROUND (GREEN WIRE).

2.2 Liquid Coolant - Liquid Carbon Dioxide (LCO_2) - 1050 psi system (standard). Optional systems are LCO_2 - 300 psi, and Liquid Nitrogen (LN_2) - 100 psi.

2.2.1 Liquid Carbon Dioxide - 1050 psi system. A siphon type liquid CO_2 bottle is recommended.

2.2.1.1 Test the bottle by releasing a small amount of LCO_2 into a white handkerchief. Any brown stain indicates rust which would clog the filter and valve in the chamber. A wet handkerchief indicates water which would either freeze in the valve or clog the injector nozzle. Crack the LCO_2 valve open on the cylinder and notice the spray. It should be a dense, white cloud. It looks thin and gray when the tank is almost empty. An almost empty tank will not give proper cooling and should not be used. Connect the tank of LCO_2 to the rear of the chamber with the supplied high-pressure hose and fittings. Place a small amount of sealing compound on the threads of the male fitting to prevent leakage. DO NOT LET ANY SEALING COMPOUND GET INTO THE VALVE INLET ON THE REAR OF THE CHAMBER. Open the bottle and check for leaks which show as frosty spots on the hose or fittings.

2.2.2 Liquid Carbon Dioxide - 300 psi Low Pressure system.

2.2.2.1 When the in-plant use of liquid CO_2 exceeds approximately 1000 to 2000 pounds per month, a bulk liquid storage system can be installed to reduce the cost of coolant.

Chambers being operated with this type of system have to be fitted with a different CO₂ valve and injector than used on a 1050 psi system. Contact Delta for information concerning valve replacement. If new chambers are ordered for use with a bulk storage 300 psi system, the fact should be stated on the order.

NOTE: The bulk storage system should be of the recirculating type if possible. If not, the supply should be located as close as possible to the chamber to minimize gas formation in the supply line. This is particularly important in low volume usage systems as the insulation and fluid flow are the factors that prevent boiling of CO₂ in the supply line. Gaseous CO₂ is not an effective coolant.

2.2.2.2 All lines, valves and connecting hoses should be blown out before the chamber is connected. Water is very troublesome and is apparently inherent in some low-pressure refrigerated supplies. If lines are opened to bleed off excessive pressure at shutdown, close them to prevent contamination by condensed moisture. This will help to keep ice from forming in the control valve.

2.3 Liquid Nitrogen

CAUTION

Oxygen in the air surrounding the chamber inner liner and in the insulation can be liquified at low temperatures. This creates an oxygen rich atmosphere surrounding the heater area. The chamber tends to be self purging as the nitrogen replaces the usual atmosphere near the heaters. Any mixture of oil and liquid oxygen can be explosive so that extreme care must be used during operation at very low temperatures.

2.3.1 A 100 psi valve and stainless steel injector assembly is used for the liquid nitrogen applications. LCO₂ from a tank will not operate properly in a chamber equipped for LN₂.

2.3.2 Connect a liquid nitrogen liquid withdrawal container to the LN₂ input of the chamber with an insulated transfer line. A relief valve should be installed in the line with a relief pressure between 60 and 100 psi for a 2700 cubic foot 50 psi liquid withdrawal container.

3 STARTING UP PROCEDURE

3.1 Precautions

3.1.1 Connect SAFETY PLUG (rear of chamber) when external programmer is not being used. This will preclude any accidental high temperature being obtained if the MODE switch is placed in the PROGRAM position with no programmer connected.

3.1.2 Unplug the chamber from all sources of power before attempting any type of servicing or removal of the controller chassis. The case of the triac switch assembly, located on the controller sub-assembly, is at power line potential and extreme care in servicing or calibration must be exercised.

3.1.3 Insure that the correct type of LCO_2 (liquid carbon dioxide) source is connected to the chamber before operating at low temperature. Recommend standard 50 pound capacity high dry siphon LCO_2 supply. Test the LCO_2 for cleanliness by discharging a quantity of it through a clean white handkerchief. Bits of rust and traces of oil, ice or water indicate contaminated LCO_2 which should not be used.

3.1.4 Ground the case of the chamber to earth ground. When a grounded outlet is not available, use the three-to-two adapter (supplied with the chamber) and connect the green colored "pigtail" to earth ground. The chamber must not be operated without the case grounded.

3.1.5 Operate the chamber at a temperature of 200°C for an hour after prolonged operation at low temperatures. This restores the efficiency of the insulating material by driving out the moisture which has been condensed out of the air.

CAUTION

Liquid oxygen may be formed in the insulation when the chamber is operated at low temperatures. Any mixture of oil and liquid oxygen can be explosive. If oil contamination is suspected, bake the chamber out by operating it at a temperature of 200°C for a period of 3 hours before taking it to extremely low temperatures.

3.1.6 Do not leave liquid nitrogen trapped in a line (valves closed at both ends) as high pressures will be developed as the liquid absorbs heat and becomes gas.

3.2 Controls - See Figure 2.

3.3 Adjusting the Failsafe

3.3.1 To adjust the FAILSAFE high temperature protection unit, rotate the slotted FAILSAFE control. The trip temperature is increased by rotating the control counterclockwise and is lowered by turning the control clockwise. The FAILSAFE setting is preset at the factory at +315°C (maximum rating of standard chamber). If it is desirable to change the setting to a lower temperature setting, operate the chamber at the maximum temperature desired. Adjust the FAILSAFE until it is on the verge of tripping.

CAUTION

Do not rotate the FAILSAFE setting more than one full turn lower than the trip point, as this can damage the unit.

3.4 Setting the Dial Temperature Indicator

3.4.1 Refer to example A - Set both dials at zero.

3.4.2 One complete rotation of the knob equals 100° . Clockwise is plus (+) degrees (F. or C) and counter-clockwise is minus (-) degrees. Each rotation of the knob is indicated by the small dial nearest the knob.

3.4.3 The large dial indicates each degree, every tenth numbered. Thus, as in example B, the large dial is set at 15, and the small dial is beyond 3, therefore the setting is $+315^{\circ}$.

3.4.4 When setting to a minus (-) temperature it is necessary to subtract the degrees from 100, i.e., 20 from 100 equals "80" reading on the large dial to have a setting of -20° . This is shown in example C. It will be noted that the zero on the small dial is just to the left of the marker. Also, on the models having a range greater than -100° , it is necessary to keep track of the counter-clockwise rotation of the knob.




FIGURE 1
TEMPERATURE SET DIAL

4 PROGRAMMING

4.1 Connect the correct resistances between pins 1 and 3 of the PROGRAM jack. Set the MODE switch to PROGRAM and the HEAT AND COOL switches to their ON positions. The controller will apply heat or coolant as needed to obtain the programmed temperature.

4.2 A safety plug is provided with the chamber and should be kept connected to the PROGRAM input whenever an actual programmer or actual resistance is not connected. The safety plug will prevent the chamber from accidentally being programmed to a very high temperature if the MODE switch is placed in the PROGRAM position with an open PROGRAM input.

4.3 The safety plug disables the heat and cool circuits of the controller when the MODE switch is placed in the PROGRAM position.

5 WARRANTY

Delta Design, Inc. guarantees all products manufactured and sold by it to conform to published specifications and against defective material and workmanship for a period of 90 days from the date of our shipment. Temperature chambers and electronics are warranted for one year from date of shipment. All contactor assemblies are warranted for a period of 90 days or 1/2 million cycles. Obligation under these warranties is limited to repair or replacement by Delta at its plant or one of its authorized service stations, on any of our products which Delta determines to be defective or not in accord with stated specifications. Delta will not accept responsibility for any defect caused by improper use, nor will Delta assume liability for any unauthorized repairs or modifications to its products or materials, even though defective or not in accord with the specifications. In no case will responsibility extend to products, materials, or equipment not manufactured by Delta. All products to be returned to Delta's plant for warranty repair must have prior written approval from Delta Design, Inc., and all return transportation charges will be at the buyer's expense. Delta will not accept liability for any unauthorized returns. No liability will be accepted for any damages to customer's materials, and equipment due to the use or misuse of Delta's products, nor for any loss of profits or other special damages. Delta Design, Inc., reserves the right to change price, design features and/or specifications without notice.

TROUBLE SHOOTING: ELECTRICAL

HOW TO USE THIS CHART

1. Turn Mode Switch to Manual.
 2. Note Thermometer Reading (Chamber Temperature)
 3. Turn Heat and Cool Switches On.
 4. Turn Temperature Set Control 50° Higher than Chamber Temperature and note the conditions of the Heat and Cool Lamps.
 5. Turn Temperature Set Control 50° Lower than Chamber Temperature and note the conditions of the Heat and Cool Lamps.
- These two situations determine the correct block to read in the chart:
6. Enter the Chart at the Top for the conditions observed in step 4. (50° Higher than Chamber Temperature.)
 7. Enter the Chart at the Left Side for the conditions observed in step 5. (50° Lower than Chamber Temperature.)

LIGHT STATE WITH TEMPERATURE SET DIAL 50° HIGHER THAN CHAMBER TEMP.			
LIGHT STATE WITH TEMPERATURE SET DIAL 50° LOWER THAN CHAMBER TEMP.			
	RED - OFF GREEN - OFF	RED - ON GREEN - OFF	RED - OFF GREEN - ON
RED - OFF GREEN - OFF	Probe Element shorted to case. (Replace) Failure on Amplifier P.C. Board. (Trace signal with scope) Transformer Winding open.	Cool Circuit has failed. Trace signals with scope.	
RED - ON GREEN - OFF		Probe shorted out. Temp. set Pot. — open, Cool Anticipator winding open. Check between Terminal A and Case of Q8 for 10Ω.	
RED - OFF GREEN - ON	Failsafe Relay K1 not energizing. Coil resistance will be Approx. 10K. Failsafe open. Heat Triac failed.	NORMAL	Probe Open. Temp. Set. Pot. shorted. Heat Anticipator Wind- ing open: Check between B and Case of Q9 for 10Ω.
RED - ON GREEN - ON		Heat circuit has failed — Trace signal with scope. Triac failed.	Cool Circuit has failed — Trace signal with scope.

TROUBLE SHOOTING:
ELECTRICAL

FAILSAFE ADJUST-LOCATED ON FRONT OF CHAMBER TURN TO CHANGE TEMPERATURE AT WHICH FAILSAFE WILL TRIP CAUTION: DO NOT LOWER FAILSAFE TEMP. SETTING UNLESS HEAT SW. IS ON & FAILSAFE IS OFF.

FAILSAFE LAMP- GLOWS RED WHEN FAILSAFE IS TRIPPED

⑤ HEAT SWITCH & LIGHT-- SWITCH ON--ON POSITION ALLOWS CONTROLLER TO APPLY HEAT AUTOMATICALLY TO MAINTAIN SELECTED TEMPERATURE IN CHAMBER RED LIGHT IS ON STEADY WHEN CHAMBER IS HEATING, BLINKS WHEN CHAMBER REACHES SELECTED TEMPERATURE ABOVE AMBIENT

④ COOL SWITCH & LIGHT--SWITCH ON--ON POSITION ALLOWS CONTROLLER TO APPLY COOLANT AUTOMATICALLY TO MAINTAIN SELECTED TEMPERATURE IN CHAMBER GREEN LIGHT IS ON STEADY WHEN CHAMBER IS COOLING.

③ POWER SWITCH & LIGHT--SWITCH ON MAIN POWER ON. WHITE LIGHT GLOWS WHEN POWER IS ON.

② TEMPERATURE SET DIAL--SET TO DESIRED TEMPERATURE. SELECTS CHAMBER TEMPERATURE IF MODE SWITCH IS IN MANUAL POSITION.

① MODE SWITCH-- SET TO MANUAL POSITION. ASSIGNS THE SELECTION OF CHAMBER TEMPERATURE TO TEMPERATURE SET DIAL OR EXTERNAL PROGRAMMER.

MANUAL POSITION: TEMPERATURE SET DIAL DETERMINES CHAMBER TEMPERATURE.

THERMOMETER- INDICATES CHAMBER TEMP. IN TEST VOLUME.


OPERATING INSTRUCTIONS:

A. INSTALL THE CHAMBER, CONNECT POWER CORD TO SUITABLE OUTLET & COOLANT SUPPLY TO VALVE INLET.


B. FOLLOW STEPS 1 THRU 5.

PROGRAM POSITION: PROGRAMMING RESISTANCE CONNECTED TO PROGRAM JACK AT REAR OF UNIT SELECTS CHAMBER TEMPERATURE

CAUTION: ALWAYS CONNECT SAFETY PLUG (AT REAR OF CHAMBER) WHEN AN EXTERNAL PROGRAMMER IS NOT BEING USED



OPERATING INSTRUCTIONS
FIGURE 2



SIDE VIEW

FIGURE 3

CHAMBER AIR FLOW PATTERN

TO REMOVE CO₂ VALVE


1. UNPLUG CHAMBER POWER CORD
2. REMOVE SIDE PANEL
3. REMOVE WIRES FROM TB2
4. REMOVE MOUNTING SCREWS (A) SEE CO₂ VALVE REMOVAL CHART
5. PULL CO₂ VALVE STRAIGHT OUT
6. AVOID BENDING OR DAMAGE TO INJECTOR STEM.

TO REMOVE BLOWERS

1. UNPLUG CHAMBER POWER CORD.
2. REMOVE 4 SCREWS B, C, D, E
3. REMOVE GRILL
3. REMOVE (2) WIRE NUTS
4. REMOVE (2) #10 SCREWS AT F & G.
5. PULL MOTOR STRAIGHT OUT

TO REMOVE HEATERS

1. UNPLUG CHAMBER POWER CORD
2. REMOVE SCREWS FROM REAR COVER
3. UNPACK FIBERGLAS
4. DISCONNECT HEATER WIRES
5. REMOVE (6) SCREWS, M, N, O, P, Q, R
6. PULL OUT HEATER ASSY.



TO REMOVE LN₂ VALVE WHEN USED

1. UNPLUG CHAMBER POWER CORD
2. REMOVE (4) SCREWS AT H, J, K, L
3. PULL LN₂ PACKAGE DIRECTLY TO REAR TO CLEAR LN₂ INJECTOR TUBE.
4. REMOVE WIRE NUTS.

FIGURE 4
CO₂ - LN₂ VALVE REMOVAL





FIGURE 5

TEMPERATURE CONTROL SYSTEM
SOLID STATE, TYPE III
DELTA DESIGN INC.



NOTE: THIS SHT SHOWS CHAMBER WIRING FOR USE WITH TYPE III CONTROLLER. SEE SHT 2 FOR TYPE IV.

- USED ON CO2 L/N2 DUAL MODEL ONLY
- E7 TO TB1 L/E5 TO TB1H DISCONNECTED AND NOT USED ON CO2 L/N2 DUAL MODEL ONLY
- E7 & E8 DISCONNECTED AND NOT USED ON L/N2 MODEL ONLY
- E5 & E6 DISCONNECTED AND NOT USED ON CO2 MODEL ONLY
- THICK LINES INDICATE HEAT POWER CIRCUIT.

CAUTION-DO NOT REMOVE P2 UNLESS A PROGRAMMER IS TO BE INSTALLED.

NOTES:

REVISION	DATE	BY	CHKD	DESCRIPTION
1	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
2	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
3	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
4	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
5	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
6	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
7	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
8	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
9	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
10	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774

REVISION	DATE	BY	CHKD	DESCRIPTION
1	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
2	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
3	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
4	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
5	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
6	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
7	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
8	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
9	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
10	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774

REVISION	DATE	BY	CHKD	DESCRIPTION
1	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
2	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
3	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
4	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
5	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
6	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
7	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
8	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
9	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774
10	1/2/78	WJ	WJ	REVISED PER ENHANCEMENT 824774



SCHEMATIC DIAGRAM
240V W/L2 AND DUAL
OPTIONS

1635838

BLUE CARD 1

REVISIONS

ZONE	LTR.	DESCRIPTION	DATE	APPROVED
A		PER ECN M683 REWORKS 5-28-74 ADDED BRACKET, PICTURE CHASE ONLY	5-28-74	M. J. J. 5-29-74




2. DISCARD PAPER WASHERS SUPPLIED WITH ITEM NO. 3. REPLACE WITH ITEM NO. 5.

1. ALL DIM. REF ONLY

NOTES:

UNLESS OTHERWISE SPECIFIED THE FOLLOWING APPLIES TO ALL DIMENSIONS: DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED. MAX. SURFACE ROUGHNESS: 125 RMS INT. CL. 28, EXT. CL. 24.

QTY. REQ'D		NOMENCLATURE OR DESCRIPTION		CODE IDENT.	IDENTIFYING NUMBER	SPECIFICATION	MATERIAL OR NOTE	ITEM NO.
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES UNLESS OTHERWISE SPECIFIED		DESIGN		BY	DATE			
FRACTIONS 64 ANGLES 1/2"		DRAFTED		ANAPP	5-2-72			
DECIMALS .XX .010		CHECKED		Hamm	7-6-72			
THOUS. .XXX .005		APPROV.		LELLA	7-6-72			
MATERIAL:		DO NOT SCALE DRAWING		PART NO.				
FINISH		2635402		2850				
NEXT ASSY		USED ON		APPLICATION				
SERIAL NOS		DATE EFF		EFFECTIVITY				
DWG. REV LTR.		DATE EFF		EFFECTIVITY				
TITLE		HEATER ASSY.		DRAWING NO.				
SIZE		B		CODE IDENT.				
SCALE		FULL		SHEET				
REV LTR.		2622520		REV LTR.				



DASH NO	A	B	USED ON
-001	8.62	3.75	2300
-002	10.12	5.50	2850
-003	7.00	6.00	7650
-004	9.18	6.00	5900
-005	26.62	20.00	2850
-006			
-007			
-008			
-009			
-010			

3 INSERT ITEM 2, TUBE, ALL THE WAY TO VALVES
INNER ORIFICE BEFORE TIGHTENING
DOWN TUBE FITTINGS

FINISH (IF APPLICABLE)


MATL (IF APPLICABLE)

NOTES: UNLESS OTHERWISE SPECIFIED

REVISIONS

ZONE	LTR	DESCRIPTION	DATE	APPD
	A	PER ECN M694 DTD 6-4-74 FLD 4.75 DIM WAS 3.75	11/28/74	6-16-74
	B	PER ECN M747 REVISION 6-24-74 -001 "B" DIM WAS 4.75	7-8-74	11/28/74
	C	PER ECN M1012 OLENIK 6-11-75 -002 "A" DIM WAS 10.44 "B" DIM WAS 3.00	6/12/75	12/1/75
	D	PER ECN M1017 OLENIK 7-16-75	11/20/75	12/1/75
	E	PER ECN 1365 BGM 3-28-78 VALVE ASSY ITEM 4 UPDATED, SEE ECN - TABULATION BLOCK 450 WAS 300	4-13-78	12/1/78
	F	PER ECN M1521 BGM 7-20-78 INJECTOR ASSY ITEM 2 UPDATED, A+B DIMS CHANGED IN TABULATION BLOCK, SEE ECN	7-31-78	12/1/78

ENGINEERING ACTIVITY DESIGN: <i>HNAPP 3-29-73</i> DRAFTED: <i>HNAPP 3-29-73</i> CHECKED: <i>HNAPP 3-29-73</i> APPROV: <i>HNAPP 3-29-73</i> RELEASE: <i>HNAPP 3-29-73</i>		DELTA DESIGN INC. A SUBSIDIARY OF COMU INC. 5723 KEARNY VILLA RD SAN DIEGO, CA 92123 - TEL (714) 293-5000	
TITLE: <i>CO₂ ASSY (900 PSI)</i> SIZE: <i>SINGLE STEM</i>		CODE IDENT: <i>2618016</i>	
DO NOT SCALE DWG		SCALE: <i>1/2" X</i>	
SHEET: <i>L</i> OF: <i>L</i>		INITIAL: <i>RELEASE ECN M2</i>	




3. INSERT ITEM 2 TUBE ALL THE WAY TO VALVE'S INNER ORIFICE BEFORE TIGHTENING TUBE FITTINGS

△ MATL (if applicable)

NOTES: UNLESS OTHERWISE SPECIFIED

[illegible]



DASH	PSI	PN
-001	900	1800117
-002	300	1800105


DELTA DESIGN INC. A SUBSIDIARY OF CONU INC. SAN DIEGO, CA. 92123		TITLE: CO ₂ VALVE + BRACKET ASSY		SIZE B		CODE IDENT 1647407		SCALE 1/1		SHEET OF	
ENGINEERING ACTIVITY				DESIGN		DO NO		SCALE		DWG	
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON				DRAFTED BGM 3-24-78		CHECKED		APPROV		RELEASE	
DECIMALS .XX : .03 .XXX : .010				ANGLE ° ' 30"		DO NO		SCALE		DWG	
TOLERANCES ON				ASSEMBLY TOLERANCES		MATERIAL		FINISH		EFFECTIVITY	
.XX : .03 .XXX : .010				.010 .005 .003 .001		.010 .005 .003 .001		.010 .005 .003 .001		.010 .005 .003 .001	
MULTI-USE				DATE EFF		DWG REV		SERIAL NO.		APPLICATION	
NEXT ASSY				DATE EFF		DWG REV		SERIAL NO.		APPLICATION	
LAST QTY				DATE EFF		DWG REV		SERIAL NO.		APPLICATION	

△ FINISH (IF APPLICABLE)

Δ MATL (IF APPLICABLE)

NOTES: UNLESS OTHERWISE SPECIFIED

REVISIONS		
ZONE	LTR	DATE
DESCRIPTION		
APPD		



4) FOR INSTRUCTIONS ON HOW TO ASSEMBLE SEE NEXT ASSEMBLY

△ REMOVE ALL BURRS & SHARP EDGES CLEAR I.D. OF ANY OBSTRUCTIONS

△ FINISH (IF APPLICABLE)

△ MATL (IF APPLICABLE)

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ON				ENGINEERING ACTIVITY		DELTA DESIGN INC.	
DECIMALS				ECN M1521		A FUSION TECHNOLOGY INC.	
FRACTIONS				DESIGN		SAN DIEGO, CA 92123	
ANGLES				DRAFTED		TITLE:	
HOLE TOLERANCE				CHECKED		INJECTOR ASSY, CO ₂	
MATERIAL				APPROV		SINGLE STEM	
FINISH				RELEASE		SIZE CODE IDENT	
EFFECTIVITY				DO NO SCALE DWG		SCALE	
APPLICATION				SHEET		OF	
DASH QTY NEXT ASSY USED ON				B		1647840	
2618016	-002						
2618015	-001						

NOTES: UNLESS OTHERWISE SPECIFIED

BLUE CARD

INDEX OF ASSEMBLIES - 2850 CHAMBER

	<u>TITLE</u>	<u>SIZE & NO.</u>	<u>SHEET</u>
1).	Chamber Ass'y	D2635402	1
2).	Innerliner Ass'y	D2635382	1
3).	Innerliner Spotweld Ass'y	D2635381	1
4).	Sheet, Top Ass'y	C2635380	1
5).	Sheet, Bottom Ass'y	C2635377	1
6).	Sheet, R. Baffle Ass'y	B2635371	2
7).	Can Ass'y	B2632196	2
8).	Partition Ass'y	D1643276	3
9).	Panel Ass'y, Rear	D2635394	3
10).	Panel Ass'y, R. Side	D2635396	3
11).	Panel Ass'y, Bottom	D2635397	3
12).	Bezel Ass'y	D2635401	3
13).	Cable Ass'y W1	A2635264	4
14).	Cable Ass'y W2	A2635265	4
15).	Weld Ass'y, Tube Guide	B1640309	4
16).	Motor Ass'y, Blower	D2621006	4
17).	Thermoswitch Ass'y	B2602503	5
18).	Heater Ass'y	B2622520	5
19).	Element Ass'y, 20ohm	B2635875	5
20).	CO ₂ Ass'y	B2618016	6
21).	Injector Ass'y, CO ₂ Single Stem	~~B1647840~~	6
22).	CO ₂ Valve & Bracket Ass'y	B1647407	6
23).	Plate Ass'y, Power	C2635057	7
24).	Capacitor Ass'y, Mod	A2635048	7
25).	Cable Ass'y	A2635833	8

Index Of Assemblies 2850 (cont.)

	<u>TITLE</u>	<u>SIZE & NO.</u>	<u>SHEET</u>
26).	Ship Kit Ass'y	C2618020	10
27).	CO ₂ Ass'y, Single Stem	B2618015	11
28).	Injector Ass'y CO ₂ Single Stem	B1647840	11
29).	CO ₂ Vlave & Bracket Ass'y	B1647407	11

ITEM NO		ASSY & QTY		INDENTURE		PL. 2635402		REV		SHT 1 OF 11		REV EGN DATE BY APP		STOCK OR PART NO.		QTY FAB		PURCHASING		S.O. NO.		PROM DATE		ACT	
						DESCRIPTION		MFG OR MFG NO		STOCK OR PART NO.		QTY FAB		PURCHASING		S.O. NO.		PROM DATE		ACT					
						DRAWING NO.		MFG OR MFG NO		STOCK OR PART NO.		QTY FAB		PURCHASING		S.O. NO.		PROM DATE		ACT					
00							D 2635402				CHAMBER ASS'Y (2850)														
00							D 1635840				SCHEMATIC														
00							D 1635838				SCHEMATIC 240 VAC														
00							C 1635836				125 TO 240 VAC CONVERSION														
00							C 1640222				LN12 INSTAL. ASSY - VALCOR VALVE (IN FIELD)														
00							D 1643453				C02 TO LN12 CHMB. CONVERSION														
00							D 2639166				C02-LN12 DUAL CONVERSION														
00							D 1640082				B OPTION C02 TO LN12 WITH REDUNDANT VALVE														
00							D 1640082				B OPTION C02-LN12 DUAL WITH REDUNDANT VALVE														
00							PL 1648289				TOP ASSY, TYPE III CONTROLLER														
01							D 2635382				B INNERLINER ASS'Y														
00																									
00							D 2635381				A INNERLINER SPOTWELD ASS'Y														
01							C 2635380				A SHEET, TOP ASS'Y														
00							C 2635380				A SHEET, TOP														
01							A 1635379				SHEET, ANGLE														
02							A 1635378				SHEET, DEFLECTOR														
03							B 1635366				SHEET, ANGLE														
04																									
05																									
06																									
02							C 2635377				SHEET, BOTTOM ASS'Y														
00																									
01							C 2635377				SHEET, BOTTOM														
02							A 1635379				SHEET, ANGLE														
03							B 1635366				SHEET, ANGLE														
04																									
05																									

NOTES: Δ THESE DWGS. ARE FOR OPTIONAL EQUIP ONLY, AND ARE NOT PART OF BASIC CHAMBER.




P/L 2635402

ITEM NO	ASSY & QTY		INDENTURE	PL 2635402		REV TOP ASS'Y (2850)		SHT 2 OF 11		REV EGN DATE BY APP		STOCK OR PART NO		JOB NO.		S O NO	
	DESCRIPTION	END ITEM BY		TOP ASS'Y	REV	SHT	OF	REV	EGN	DATE	BY	APP	STOCK OR PART NO	STOCK OR PART NO	JOB QTY	QTY	PROM DATE
	DRAWING NO.	DESCRIPTION	MFG OR MFG NO	STOCK OR PART NO	JOB QTY	QTY	PROM DATE	ACT									
01	1635376	C SHEET, RIGHT		1635376	1	1						1635376	1635376				
02	1635375	B SHEET, LEFT		1635375	1	1						1635375	1635375				
03	1635373	B SHEET, TOP DEFLECTOR		1635373	1	1						1635373	1635373				
04	1635372	A SHEET, BOTTOM DEFLECTOR		1635372	1	1						1635372	1635372				
05	1630007	C RETAINER		1630007	1	1						1630007	1630007				
06	1634771	C TUBE, CO2 VENT		1634771	1	1						1634771-005	1634771-005				
07	1634780	E TUBE, L&L GUIDE		1634780	1	1						1634780-010	1634780-010				
08	1634774	B TUBE, PROBE GUIDE		1634774	1	1						1634774-004	1634774-004				
09																	
10																	
11																	
12																	
13																	
14																	
15																	
16																	
17	2635371	SHEET, RIGHT BAFFLE ASSY		2635371	1	1						2635371	2635371				
18	1635370	SHEET, RIGHT BAFFLE		1635370	1	1						1635370	1635370				
19	1635369	SHEET, PROBE GUARD		1635369	1	1						1635369	1635369				
20	1635368	SHEET, LEFT BAFFLE		1635368	1	1						1635368	1635368				
21	1635367	B SCROLL		1635367	1	1						M/F 2100701	M/F 2100701				
22	2632196	D CAN ASS'Y		2632196	1	1						2632196-004	2632196-004				
23	1632350	C CAN		1632350	1	1						1632350-004	1632350-004				
24	1631838	A TAB		1631838	2	2						1631838	1631838				
25		GROMMET			1	1						1500026	1500026				
26		* 4 x 1/4 PHP-SMS			16	16						6904142-400	6904142-400				
27		* 6 x 3/8 PHP-SMS			6	6						6906382-400	6906382-400				
28	1600015	SCROLL RING		1600015	1	1						1600015	1600015				
29	1635374	SHEET, BACK		1635374	1	1						1635374	1635374				

P/L 2635402

NOTES:

ITEM NO	ASSY B QTY		INDENTURE	PL 2635402		REV 3 OF 11		REV ECN DATE BY APP		STOCK OR PART NO.	QTY FAB REC CD	PURCHASING P.O. NO.	QTY DUE REC'D	MANUFACTURE ACT EST ACT	PLATE/PAINT IN OUT
	1000	1002		1000	1004	DESCRIPTION TOP ASSY (2850)	SHT 3	DATE	DATE						
10															
11															
12															
13															
14															
02															
00															
01															
02															
03															
04															
03															
00															
01															
02															
03															
04															
05															
00															
01															
02															
03															
04															
06															
00															
01															
02															
03															
04															
07															
08															
09															
NOTES:															

ITEM NO		ASSY 8 QTY		INDENTURE		PL. 2635402		REV. SHT 4 OF 11		REV ECN DATE BY		 DELTA DESIGN 5725 HEARY VILLA RD SAN DIEGO, CALIF		JOB NO		S.O. NO	
DESCRIPTION		TOP ASSY 2850 CHAMBER		END ITEM BY		REV. SHT 4 OF 11		REV ECN DATE BY		REV ECN DATE BY		 DELTA DESIGN 5725 HEARY VILLA RD SAN DIEGO, CALIF		QTY		FROM DATE	
NEXT ASSY		END ITEM BY		REV. SHT 4 OF 11		REV ECN DATE BY		REV ECN DATE BY		REV ECN DATE BY		 DELTA DESIGN 5725 HEARY VILLA RD SAN DIEGO, CALIF		QTY		MACH	
DRAWING NO.		REV		DESCRIPTION		MFG OR MFG NO		STOCK OR PART NO		QTY		QTY		QTY		QTY	
00																	
01		2		B	1634689	B	ANGLE, BEZEL										
02		2		B	1634689	B	ANGLE, BEZEL										
03																	
04		1		A	2635264	A	CABLE ASS'Y. (W1)										
05																	
06																	
07																	
08																	
09																	
10																	
11																	
12																	
13																	
14																	
15																	
16																	
17																	
18																	
19																	
20																	
21																	
22																	
23																	
24																	

NOTES:

P/L 2635402

ITEM NO		ASSY & QTY		PL 2635402		REV 5 OF 11		REV ECN DATE BY APP		STOCK OR PART NO		QTY FAB REC CD		PURCHASING		MANUFACT JRE	
DESCRIPTION		QTY		TOP ASSY (P850)		SHT 5 OF 11		REV ECN DATE BY APP		STOCK OR PART NO		QTY FAB REC CD		PURCHASING		MANUFACT JRE	
NEXT ASSY END ITEM BY		QTY		TOP ASSY (P850)		SHT 5 OF 11		REV ECN DATE BY APP		STOCK OR PART NO		QTY FAB REC CD		PURCHASING		MANUFACT JRE	
INDENTURE		QTY		TOP ASSY (P850)		SHT 5 OF 11		REV ECN DATE BY APP		STOCK OR PART NO		QTY FAB REC CD		PURCHASING		MANUFACT JRE	
INDENTURE		QTY		TOP ASSY (P850)		SHT 5 OF 11		REV ECN DATE BY APP		STOCK OR PART NO		QTY FAB REC CD		PURCHASING		MANUFACT JRE	
05	4																
06	1																
07	1																
08	1																
09	1																
10	4																
11																	
12																	
13																	
14																	
18	2																
19	2																
20	4																
21	1																
22	1																
23	1																
00																	
01	1																
02	1																
03																	
24	1																
25	1																
26	1																
27	1																
00																	
01	1																
02	4																
03	4																
04	2																
00																	
01	1																
02	2																
03	2																

NOTES: A USE ONLY AS REQ'D. TO OPTIMIZE SEAL.

A ITEMS 243 ARE SEPARATED FROM STK. ITEM 1500327 AND SUPPLIED TO VENDOR.

P/L 2635402

ITEM NO	ASSY & QTY	INDENTURE	PL. 2635402		REV	SHT 6 OF 11	REV ECN DATE BY APP	STOCK OR PART NO	QTY FAB REC CD	PURCHASING P.O. NO.	QTY/DUE RECSTD	MANUFACTURE ACT EST ACT PAINT IN OUT
			DESCRIPTION	TOP ASSY (2850)								
04												
05												
06												
07												
08												
28												
00												
01												
02												
00												
04												
01												
02												
03												
04												
00												
01												
02												
03												
04												
05												
06												
07												
08												
09												
10												
05												
06												
29												
30												
00												

NOTES: **A** CO₂ PSI OPTIONAL PER CUSTOMER PREFERENCE

P/L 2635402

ITEM NO		ASSY 8 QTY		PL. 2635402		REV. 7 OF 11		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
DESCRIPTION		TOP ASSY (2850)		DESCRIPTION		SHT 7 OF 11		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
NEXT ASSY END ITEM BY APP		END ITEM BY APP		NEXT ASSY END ITEM BY APP		END ITEM BY APP		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
DRAWING NO.		DRAWING NO.		DRAWING NO.		DRAWING NO.		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
B 1635054		C 1635054		C 1635054		C 1635054		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
B 2600409		B 2600409		B 2600409		B 2600409		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
PANEL, SIGNAL		PANEL, SIGNAL		PANEL, SIGNAL		PANEL, SIGNAL		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
PLUG MOD, AMPHENUOL		PLUG MOD, AMPHENUOL		PLUG MOD, AMPHENUOL		PLUG MOD, AMPHENUOL		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
PLUG, 4 PIN AUDIO		PLUG, 4 PIN AUDIO		PLUG, 4 PIN AUDIO		PLUG, 4 PIN AUDIO		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
CHAIN, 4"		CHAIN, 4"		CHAIN, 4"		CHAIN, 4"		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
* 6 EYELET		* 6 EYELET		* 6 EYELET		* 6 EYELET		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
* 2-56 x 3/32 PHP-MS		* 2-56 x 3/32 PHP-MS		* 2-56 x 3/32 PHP-MS		* 2-56 x 3/32 PHP-MS		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
WIRE, 20 GA BUS		WIRE, 20 GA BUS		WIRE, 20 GA BUS		WIRE, 20 GA BUS		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
* 2 FLAT WASHER		* 2 FLAT WASHER		* 2 FLAT WASHER		* 2 FLAT WASHER		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
SOCKET		SOCKET		SOCKET		SOCKET		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
TERMINAL BLOCK		TERMINAL BLOCK		TERMINAL BLOCK		TERMINAL BLOCK		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
* 6 x 1/2" PHP-SMS		* 6 x 1/2" PHP-SMS		* 6 x 1/2" PHP-SMS		* 6 x 1/2" PHP-SMS		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
* 6-32 x 3/4 PHP-MS		* 6-32 x 3/4 PHP-MS		* 6-32 x 3/4 PHP-MS		* 6-32 x 3/4 PHP-MS		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
PANEL ASSY, POWER		PANEL ASSY, POWER		PANEL ASSY, POWER		PANEL ASSY, POWER		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
PLATE ASSY, POWER		PLATE ASSY, POWER		PLATE ASSY, POWER		PLATE ASSY, POWER		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
SILKSCREEN MASTER		SILKSCREEN MASTER		SILKSCREEN MASTER		SILKSCREEN MASTER		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
PANEL .08 AL ALY SHT.		PANEL .08 AL ALY SHT.		PANEL .08 AL ALY SHT.		PANEL .08 AL ALY SHT.		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
* 6-32 RIVNUT, CSK. HD.		* 6-32 RIVNUT, CSK. HD.		* 6-32 RIVNUT, CSK. HD.		* 6-32 RIVNUT, CSK. HD.		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
FUSEHOLDER		FUSEHOLDER		FUSEHOLDER		FUSEHOLDER		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
CAPACITOR, MOD.		CAPACITOR, MOD.		CAPACITOR, MOD.		CAPACITOR, MOD.		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
CAPACITOR		CAPACITOR		CAPACITOR		CAPACITOR		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
SWAGE NUT		SWAGE NUT		SWAGE NUT		SWAGE NUT		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	
NOTES:		NOTES:		NOTES:		NOTES:		REV. ECN DATE BY APP		STOCK OR PART NO		JOB NO		S.O. NO		JOB NO		S.O. NO	

P/L 2635402

[illegible]

ITEM NO	ASSY & QTY			INDENTURE		PL	REV	SHT	OF	REV	ECN	DATE BY	APP	STOCK OR PART NO	QTY FAB REC CD	PURCHASING P.O. NO.	QTY DUE	RECSTD	HRS	COM	IN	OUT	ACT	PAINT	S.O. NO	ACT
	1001	1002	1003	1004	SIZE	DESCRIPTION	REV	DRAWING NO.	DESCRIPTION	MFG OR MFG NO	REV	DATE BY	APP													
37	/					GROMMET								1500026												
38	/					PLUG (3/8 DIA HOLE)								3600082												
39	/					PLUG (1/2 DIA HOLE)								3600081												
40	/					PLUG (1/4 DIA HOLE)								1700142												
41	/					ADAPTER BUSHING								4100003												
42	/					NUT								1500735												
43	2					SPACER								1635610												
44	2					SUPPORT BLOCK - INNER LINER								1648658-101												
45	2					SOLDERLESS TERMINAL (RING)								1500062												
46																										
47																										
48	AR					WIRE, 14 AWG (TEFLON)								1500380												
49	AR					WIRE, 14 AWG				COHU 3TK.				1700614-999												
50	AR					WIRE, 20 AWG				COHU 3TK.				1700620-999												
51	2					GROMMET, 1/2"								1500032												
52	6					CABLE TIE								1500014												
53	6					PUSH MOUNT								1500013												
54	1					OUTLET, CONVENIENCE (LI)								1500083												
55	4					*4 x 1/2 PHP-SMS								6904120-400												
56																										
57																										
58	2					*6-32 x 3/8 PHP-MS								6806323-04												
59	17					*6-32 x 1/2 PHP-MS								6806321-204												
60	40					*6 x 1/2 PHP-SMS								6906126-400												
61	10					*6 x 1/2 PHP-SMS								6906120-100												
62	11					*8 x 1/2 THP-SMS								6908120-600												
63	8					*10-32 x 1/2 PHP-MS								6810321-204												
64	1					*8-32 x 1/2 THP-MS								6808321-206												
65	13					*6 LOCKWASHER								6606010												
66	6					*10 SPLIT LOCKWASHER								6610010												
67																										
68																										
69	4					*6 HEX NUT								6706320												

NOTES: A INDICATED ON SHT. 5 OF DWG.

P/L 2635402

[illegible]

ITEM NO		ASSY B QTY		INDENTURE		PL 2635402		REV		SHT		OF		APPD		REV EGN DATE BY APP		STOCK OR PART NO.		QTY ALX REC'D		27 FAB		PURCHASING		S O NO	
DESCRIPTION		TOP ASSY (2850)		NEXT ASSY		END ITEM BY BGM CK'D		REV		SHT		OF		APPD		REV EGN DATE BY APP		STOCK OR PART NO.		QTY ALX REC'D		27 FAB		PURCHASING		S O NO	
B 2618015		C		CO ₂ ASSY SINGLE STEM		(300 PSI) A																					
B 2618015		C		CO ₂ VALVE W/ GMP ASSY																							
B 1647840				INJECTOR ASSY CO ₂ SINGLE STEM																							
				FITTINGS, INJECTOR																							
				TUBE, CO ₂ INJECTOR																							
				INSULATION																							
B 1647407				CO ₂ VALVE + BRACKET ASSY																							
B 1645008				BRACKET, CO ₂																							
				NIPPLE, BRASS - 8 NPT X 2.00																							
				COUPLING, 1/8 NPT																							
				#8-32 X 3/8 PHP-MIS																							
				#8 LOCK WASHER I.D.																							
				#8 HEX NUT																							
				SOLENOID VALVE (300 PSI)																							
																								</			

—INSTRUCTIONS FOR CHAMBER RETROFIT—
TYPE V CONTROLLER


1. REMOVE CHAMBER RIGHT SIDE PANEL TO ALLOW ACCESS TO CONTROLLER & PROBE GUIDE TUBE. ON MODELS 2850, 5900 & 7650 TOP PANEL MUST BE REMOVED AS WELL.
2. REMOVE EXISTING CONTROLLER & ITS PROBE. DO NOT DESTROY BLACK PRESS-TITE.
3. NOTE CHAMBER REAR PANEL CONFIGURATION & DECIDE WHICH MEANS OF MOUNTING THE REMOTE INTERFACE CABLE ASSY. PLUG BEST SUITS YOUR CHAMBER & REQUIREMENTS
4. MAKE THE REAR PANEL MODIFICATIONS
5. MOUNT THE REMOTE INTERFACE CABLE ASSY PLUG TO THE REAR PANEL—SEE DRAWING D1650223 & PARTS LIST FOR CABLE & HARDWARE CALLOUTS
6. INSERT THERMOCOUPLE ASSY IN PROBE GUIDE TUBE & SECURE IN PLACE USING BLACK PRESS-TITE. SEE DRAWING D1650223
CAUTION—DO NOT SHORTEN THERMOCOUPLE ASSY WIRE FOR ANY REASON
7. INSTALL TYPE V CONTROLLER & WIRE PER WIRING DIAGRAM D1635840 OR D1635838 SHEET 2 OF 2. IF NECESSARY, COIL EXCESS THERMOCOUPLE WIRE & POSITION IT BETWEEN CONTROLLER & CHAMBER TO ACT AS A SERVICE LOOP IF NEEDED
8. REPLACE TOP PANEL IF YOU HAVE A MODEL 2850, 5900 OR 7650
9. BEFORE REPLACING SIDE PANEL SEE CONTROLLER MANUAL FOR SET UP & CALIBRATION PROCEDURES
10. CALIBRATE CONTROLLER
11. REPLACE SIDE PANEL

△ FINISH (IF APPLICABLE)

△ MATE (IF APPLICABLE)


NOTES: UNLESS OTHERWISE SPECIFIED

IF YOUR MODEL 2850 CHAMBER REAR PANEL LOOKS LIKE THIS, MODIFY BY:




1/2 SCALE

1. ADD CUTOUT AT DIMENSION SHOWN




1/2 SCALE

1. REMOVE OLD SIGNAL PANEL & REPLACE WITH NEW ITEM 1.



REMOTE INTERFACE CABLE ASSY PLUG CUTOUT DIMENSIONS




REVISIONS				DATE			
1	REVISED	12/19/79	12/19/79	1	REVISED	12/19/79	12/19/79
2	REVISED	12/19/79	12/19/79	2	REVISED	12/19/79	12/19/79
3	REVISED	12/19/79	12/19/79	3	REVISED	12/19/79	12/19/79
4	REVISED	12/19/79	12/19/79	4	REVISED	12/19/79	12/19/79
5	REVISED	12/19/79	12/19/79	5	REVISED	12/19/79	12/19/79
6	REVISED	12/19/79	12/19/79	6	REVISED	12/19/79	12/19/79
7	REVISED	12/19/79	12/19/79	7	REVISED	12/19/79	12/19/79
8	REVISED	12/19/79	12/19/79	8	REVISED	12/19/79	12/19/79
9	REVISED	12/19/79	12/19/79	9	REVISED	12/19/79	12/19/79
10	REVISED	12/19/79	12/19/79	10	REVISED	12/19/79	12/19/79
11	REVISED	12/19/79	12/19/79	11	REVISED	12/19/79	12/19/79
12	REVISED	12/19/79	12/19/79	12	REVISED	12/19/79	12/19/79
13	REVISED	12/19/79	12/19/79	13	REVISED	12/19/79	12/19/79
14	REVISED	12/19/79	12/19/79	14	REVISED	12/19/79	12/19/79
15	REVISED	12/19/79	12/19/79	15	REVISED	12/19/79	12/19/79
16	REVISED	12/19/79	12/19/79	16	REVISED	12/19/79	12/19/79
17	REVISED	12/19/79	12/19/79	17	REVISED	12/19/79	12/19/79
18	REVISED	12/19/79	12/19/79	18	REVISED	12/19/79	12/19/79
19	REVISED	12/19/79	12/19/79	19	REVISED	12/19/79	12/19/79
20	REVISED	12/19/79	12/19/79	20	REVISED	12/19/79	12/19/79
21	REVISED	12/19/79	12/19/79	21	REVISED	12/19/79	12/19/79
22	REVISED	12/19/79	12/19/79	22	REVISED	12/19/79	12/19/79
23	REVISED	12/19/79	12/19/79	23	REVISED	12/19/79	12/19/79
24	REVISED	12/19/79	12/19/79	24	REVISED	12/19/79	12/19/79
25	REVISED	12/19/79	12/19/79	25	REVISED	12/19/79	12/19/79
26	REVISED	12/19/79	12/19/79	26	REVISED	12/19/79	12/19/79
27	REVISED	12/19/79	12/19/79	27	REVISED	12/19/79	12/19/79
28	REVISED	12/19/79	12/19/79	28	REVISED	12/19/79	12/19/79
29	REVISED	12/19/79	12/19/79	29	REVISED	12/19/79	12/19/79
30	REVISED	12/19/79	12/19/79	30	REVISED	12/19/79	12/19/79
31	REVISED	12/19/79	12/19/79	31	REVISED	12/19/79	12/19/79
32	REVISED	12/19/79	12/19/79	32	REVISED	12/19/79	12/19/79
33	REVISED	12/19/79	12/19/79	33	REVISED	12/19/79	12/19/79
34	REVISED	12/19/79	12/19/79	34	REVISED	12/19/79	12/19/79
35	REVISED	12/19/79	12/19/79	35	REVISED	12/19/79	12/19/79
36	REVISED	12/19/79	12/19/79	36	REVISED	12/19/79	12/19/79
37	REVISED	12/19/79	12/19/79	37	REVISED	12/19/79	12/19/79
38	REVISED	12/19/79	12/19/79	38	REVISED	12/19/79	12/19/79
39	REVISED	12/19/79	12/19/79	39	REVISED	12/19/79	12/19/79
40	REVISED	12/19/79	12/19/79	40	REVISED	12/19/79	12/19/79
41	REVISED	12/19/79	12/19/79	41	REVISED	12/19/79	12/19/79
42	REVISED	12/19/79	12/19/79	42	REVISED	12/19/79	12/19/79
43	REVISED	12/19/79	12/19/79	43	REVISED	12/19/79	12/19/79
44	REVISED	12/19/79	12/19/79	44	REVISED	12/19/79	12/19/79
45	REVISED	12/19/79	12/19/79	45	REVISED	12/19/79	12/19/79
46	REVISED	12/19/79	12/19/79	46	REVISED	12/19/79	12/19/79
47	REVISED	12/19/79	12/19/79	47	REVISED	12/19/79	12/19/79
48	REVISED	12/19/79	12/19/79	48	REVISED	12/19/79	12/19/79
49	REVISED	12/19/79	12/19/79	49	REVISED	12/19/79	12/19/79
50	REVISED	12/19/79	12/19/79	50	REVISED	12/19/79	12/19/79
51	REVISED	12/19/79	12/19/79	51	REVISED	12/19/79	12/19/79
52	REVISED	12/19/79	12/19/79	52	REVISED	12/19/79	12/19/79
53	REVISED	12/19/79	12/19/79	53	REVISED	12/19/79	12/19/79
54	REVISED	12/19/79	12/19/79	54	REVISED	12/19/79	12/19/79
55	REVISED	12/19/79	12/19/79	55	REVISED	12/19/79	12/19/79
56	REVISED	12/19/79	12/19/79	56	REVISED	12/19/79	12/19/79
57	REVISED	12/19/79	12/19/79	57	REVISED	12/19/79	12/19/79
58	REVISED	12/19/79	12/19/79	58	REVISED	12/19/79	12/19/79
59	REVISED	12/19/79	12/19/79	59	REVISED	12/19/79	12/19/79
60	REVISED	12/19/79	12/19/79	60	REVISED	12/19/79	12/19/79
61	REVISED	12/19/79	12/19/79	61	REVISED	12/19/79	12/19/79
62	REVISED	12/19/79	12/19/79	62	REVISED	12/19/79	12/19/79
63	REVISED	12/19/79	12/19/79	63	REVISED	12/19/79	12/19/79
64	REVISED	12/19/79	12/19/79	64	REVISED	12/19/79	12/19/79
65	REVISED	12/19/79	12/19/79	65	REVISED	12/19/79	12/19/79
66	REVISED	12/19/79	12/19/79	66	REVISED	12/19/79	12/19/79
67	REVISED	12/19/79	12/19/79	67	REVISED	12/19/79	12/19/79
68	REVISED	12/19/79	12/19/79	68	REVISED	12/19/79	12/19/79
69	REVISED	12/19/79	12/19/79	69	REVISED	12/19/79	12/19/79
70	REVISED	12/19/79	12/19/79	70	REVISED	12/19/79	12/19/79
71	REVISED	12/19/79	12/19/79	71	REVISED	12/19/79	12/19/79
72	REVISED	12/19/79	12/19/79	72	REVISED	12/19/79	12/19/79
73	REVISED	12/19/79	12/19/79	73	REVISED	12/19/79	12/19/79
74	REVISED	12/19/79	12/19/79	74	REVISED	12/19/79	12/19/79
75	REVISED	12/19/79	12/19/79	75	REVISED	12/19/79	12/19/79
76	REVISED	12/19/79	12/19/79	76	REVISED	12/19/79	12/19/79
77	REVISED	12/19/79	12/19/79	77	REVISED	12/19/79	12/19/79
78	REVISED	12/19/79	12/19/79	78	REVISED	12/19/79	12/19/79
79	REVISED	12/19/79	12/19/79	79	REVISED	12/19/79	12/19/79
80	REVISED	12/19/79	12/19/79	80	REVISED	12/19/79	12/19/79
81	REVISED	12/19/79	12/19/79	81	REVISED	12/19/79	12/19/79
82	REVISED	12/19/79	12/19/79	82	REVISED	12/19/79	12/19/79
83	REVISED	12/19/79	12/19/79	83	REVISED	12/19/79	12/19/79
84	REVISED	12/19/79	12/19/79	84	REVISED	12/19/79	12/19/79
85	REVISED	12/19/79	12/19/79	85	REVISED	12/19/79	12/19/79
86	REVISED	12/19/79	12/19/79	86	REVISED	12/19/79	12/19/79
87	REVISED	12/19/79	12/19/79	87	REVISED	12/19/79	12/19/79
88	REVISED	12/19/79	12/19/79	88	REVISED	12/19/79	12/19/79
89	REVISED	12/19/79	12/19/79	89	REVISED	12/19/79	12/19/79
90	REVISED	12/19/79	12/19/79	90	REVISED	12/19/79	12/19/79
91	REVISED	12/19/79	12/19/79	91	REVISED	12/19/79	12/19/79
92	REVISED	12/19/79	12/19/79	92	REVISED	12/19/79	12/19/79
93	REVISED	12/19/79	12/19/79	93	REVISED	12/19/79	12/19/79
94	REVISED	12/19/79	12/19/79	94	REVISED	12/19/79	12/19/79
95	REVISED	12/19/79	12/19/79	95	REVISED	12/19/79	12/19/79
96	REVISED	12/19/79	12/19/79	96	REVISED	12/19/79	12/19/79
97	REVISED	12/19/79	12/19/79	97	REVISED	12/19/79	12/19/79
98	REVISED	12/19/79	12/19/79	98	REVISED	12/19/79	12/19/79
99	REVISED	12/19/79	12/19/79	99	REVISED	12/19/79	12/19/79
100	REVISED	12/19/79	12/19/79	100	REVISED	12/19/79	12/19/79

BLUE CARD

[illegible]

[illegible]

REVISIONS			
ZONE	LTR	DESCRIPTION	DATE
A	PER EON M 2052	THAMIE'S 9-13-50	
	TAH LATER	5-1-51	



DASH NO	"A" DIM	"B" DIM	USED ON
-001	44.4"	5.25"	2300 THRU 7650, 2850 A
-002	96.0"	5.25"	8000
-003	30.0"	8.27"	2300 A

- 4 REMOVE ALL BURRS & SHARP EDGES FROM I.D. OF ITEM 1 (BOTH ENDS)
- 3 INSURE ITEM 5 IS SOLIDLY CRIMPED OVER ITEM 4 - THEN ITEM 2 IS CRIMPED OVER ITEM 5

FINISH (IF APPLICABLE)

MATL (IF APPLICABLE)

DELTA DESIGN INC. A DIVISION OF CONA INC. SAN DIEGO, CA 92108	
TITLE: THERMOCOUPLE ASSY.	
ENGINEERING ACTIVITY M1952	SIZE: B CODE IDENT: 1650230
DESIGN: OLEJNIK 12/6/73 CHECKED: APPROV: RELEASE: DO NOT SCALE DWG	SCALE: SHEET: 1 OF 1

NOTES: UNLESS OTHERWISE SPECIFIED

[illegible]



SAN DIEGO, CALIFORNIA

www.manualsplus.com



1024520